

HECHT[®] 822

made for garden



1	JS-1601-01	stifled head25
2	JS-1601-02	extend splint
3	JS-1601-03	extend block
4	JS-1601-04	work table
5	JS-1601-05	stifled head30
6	JS-1601-06	upper crosspiece
7		nut
8	JS-1601-07	length pole
9	LS-1023-49	screw
10	JS-1601-08	extend wing pole
11		big flat mat
12		screw
13	JS-1601-09	work table support
14	JS-3051-81	extend wing
15		bolt
16		nut
17		flat mat
18		bolt
19		bolt
20	JS-1601-10	orientation plank
21	JS-1601-11	front support pole
22	JS-1601-12	feet sheath
23	LS-1023-06	screw
24	JS-1601-13	limit pin
25	JS-1601-14	work table support
26	JS-1601-15	crosspiece
27		iron chain
28	JS-1601-16	bolt
29	JS-1601-17	feet sheath
30	JS-1601-18	back support pole
31	JS-1601-19	chain base
32		bolt
33	JS-1601-20	knife rest support
34	JS-1601-21	short pole
35	JS-1601-22	limit pole
36	JS-1601-23	envelop plank
37	JS-1601-24	outer knife rest
38	JS-1601-25	motor orientation plank
39	JS-1601-26	knife rest base
40	JS-1601-27	inner knife rest stand
41		bolt
42		switch
43		screw
44		screw
45		flat mat
46	JS-1601-28	outer cover
47		nut

48		flat mat
49	JS-1601-29	outer flange
50		blade
51	JS-1601-30	inner flange
52		bolt
53		bolt
54	JS-1601-31	cover body
55	JS-1601-32	inner cover
	JS-1601-33	
	JS-1601-34	
	JS-1601-35	
	JS-1601-36	
	JS-1601-37	
56	JS-1601-38	spanner1
57	JS-1601-39	spanner
58	JS-1601-40	motor
59	JS-1601-41	front cover
60	JS-1601-42	back cover
61		A type nut
62		nut
63		washer
64	JS-1601-44	electricity cover
65	JS-1601-45	capacitance cover